

# Town of Rockingham

## Stormwater Infrastructure Mapping Project

May 2017



***VTDEC – CLEAN WATER INITIATIVE PROGRAM,  
WATERSHED MANAGEMENT DIVISION***

<https://dec.vermont.gov/water-investment/cwi/solutions/developed-lands/idde>

Jim Pease, [Jim.Pease@vermont.gov](mailto:Jim.Pease@vermont.gov)  
David Ainley, [David.Ainley@vermont.gov](mailto:David.Ainley@vermont.gov)

## Overview

This stormwater infrastructure mapping project was completed for the municipality by the Agency of Natural Resources Ecosystems Restoration program to supplement the existing drainage data collected by the town and with the intention of providing a tool for planning, maintenance, and inspection of the stormwater infrastructure.

The GIS maps and geodatabase are meant to provide an overall picture and understanding of the connectivity or connectedness of the storm system on both public and private properties. They can be used to: (1) raise the awareness of the need for regular maintenance, the generation and transport of nonpoint source pollution increases with increasing connectivity of a drainage system, (2) as a valuable tool for hazardous material spill planning and prevention, (3) for the detection and elimination of illicit discharges; outfall locations and system connectedness data are used as a base for locating illicit or illegal discharges of non-stormwater to the municipal storm system and tracing them up to the source, (4) better assist the municipality in planning and implementing combined stormwater-sewer separation projects, (5) inform options for cleaning up existing polluted stormwater discharges; this report provides information and guidance for potential retrofit treatment locations and opportunities, (6) assist municipalities and residents with emergency preparedness for large rainfall events (i.e. Tropical Storm or Hurricanes) or spring snowmelt runoff events, by keeping storm drains clean, clear and open a good deal of localized flooding could be prevented, and (7) the basis for a local stormwater ordinance or be used to help enhance an existing stormwater management program.

## Project Summary

The principal goal of this project was to develop up to date municipal drainage maps. These drainage maps were created showing the paths that stormwater runoff travels from where it falls on impervious surfaces such as parking lots, roads, and rooftops, to the outfall points in various receiving waters. These maps show the stormwater infrastructure including features like pipes, manholes, catchbasins, and swales within a municipality. Data sources included data collected from field work, a mapping grade Trimble GPS unit, available state permit plans, record drawings, town plans, WWMD plans, existing GIS data from contractors, and the input and guidance of knowledgeable members from the municipalities.

A second goal of this project was to establish potential locations for Best Management Practice (BMP) stormwater retrofit sites. These are sites where stormwater treatment structures could be added and where they would be most cost effective and efficient for sediment and phosphorus or nitrogen removal. In order to develop a retrofit site list, drainage area subwatersheds were delineated around the drainage networks. Determining how the stormwater infrastructure was connected was necessary in determining the subwatershed drainage areas within the town.

Delineating the drainage areas was done using the stormwater infrastructure maps, along with satellite imagery, a Digital Elevation Model (DEM), and USGS topographic maps. These data sources were used to approximate where the land area within each municipality was draining to; as well as where the high points were that divided the sub-drainage areas. The completed maps show the drainage coverage for essentially the entire municipality, but with a focus on areas with greater concentrations of impervious cover.

Impervious cover layers were created by either hand digitization or by using a method of raster pixel calculation (with ArcGIS spatial analyst extension) to create a vegetation index from the National Agricultural Imagery Program (NAIP) 08 orthophotos. The area which contrasted with the vegetation represents impervious surfaces and was then modified with buffered water and roads layers to make it more accurate. A more detailed explanation of this process is available in a separate document. The impervious layer was used to calculate the

percent of each delineated drainage area that would generate stormwater runoff. The percentage of impervious surface number for each subwatershed was then adjusted with a connectivity rating. A rating was assigned to each drainage area polygon describing how directly connected the impervious surfaces within that subwatershed are to the receiving water. By adjusting the percent impervious area numbers with this connectivity rating the effective impervious area (EIA) was established for each subwatershed (*Sutherland, 1995*). This effective impervious number is a more accurate description of the amount of runoff produced by each of the subwatersheds because it helps to take factors such as infiltration into account.

After the effective impervious numbers were calculated for the subwatersheds the Simple Method was used to estimate the annual sediment (TSS) and phosphorus (TP) or Nitrogen (TN) loads generated by each subwatershed. The Simple method uses information which includes the adjusted impervious value, average annual rainfall for the location, total subwatershed area, and a given pollutant concentration value to calculate an annual load for various pollutants (*Schueler, 1987*). Pollutant loads estimated by the Simple Method in this project are planning level estimates and are meant to give a general idea of the amounts of sediment or nutrient wash-off produced by each subwatershed for prioritization purposes. Subwatersheds were then prioritized, using the loading calculations as well as other criteria, and given Action List numbers ranging from 1 to 3 (one being the highest priority). The Action List number depends both upon loading values and feasibility of potential retrofit treatment options. Potential retrofit options listed in the TARGET maps are based on field observations and not on actual availability of land or willingness of landowner.

Water Quality Volume (WQv – the amount of storage needed to treat stormwater from a 0.9-1.0-inch storm) and Channel Protection Volume (CPv – the volume of storage that is needed to hold and slowly release stormwater for a 2.1 inch rain event) were also calculated for delineated subwatershed areas. CPv calculations are only applicable if the receiving water is not a large body of water and is therefore susceptible to channel erosion. These numbers were used in the retrofit recommendation process because the volume of water to be treated was a key factor in determining the type of retrofit.

### ***Project References***

*Schueler, T. 1987. Technical Documentation of a Simple Method for Estimating Urban Storm Pollutant Export. Controlling Urban Runoff: A Practical Manual for Planning and Designing Urban BMPs. Appendix A.*

*Schueler, T. et.al., 2007. Urban Stormwater Retrofit Practices, Version 1.0. Manual 3, Center for Watershed Protection, August 2007.*

*Sutherland, R. 1995. Methodology for Estimating the Effective Impervious Area of Urban Watersheds. Technical Note 58 – Pervious Area Management. Watershed Protection Techniques. Vol. 2, No. 1*

**\*All data was created in an ArcGIS 10 Geodatabase format and is available from VTDEC.**

## ***Act 64 Municipal Roads General Permit (MRGP)***

The 2015 Vermont Legislature adopted Act 64 which will require all municipalities to address stormwater runoff from all existing municipal roads. The time line for adopting this general permit is as follows: December 2016 – Draft general permit available for informal public review, Summer-Fall of 2017 public hearings and comments and review, January 2018 final general permit issued; municipalities must file notice of intents to comply with the permit, currently proposed for summer 2018. The permit will likely require:

- Municipalities will develop road Stormwater management plans (RSWMPs). RSWMPs will include a comprehensive road erosion inventory of hydrologically-connected road segments and Implementation Plan and Schedule.
- The inventory will include an evaluation municipal hydrologically-connected road segments to see if they meet new MRGP standards. Road erosion inventories will be conducted every 5 years.
- Road segments that do not currently meet MRGP standards and that can impact waterways will be prioritized for remediation within the Implementation Plan and Schedule DEC has developed an Implementation Table and Schedule Excel spread sheet template for this purpose.

Towns will submit semi-annual reports to DEC documenting progress in road BMP implementation and MRGP compliance. Municipalities will be able to use the Implementation Table and Schedule spread sheet, mentioned above, for semi-annual compliance reporting requirements. The Road Erosion Inventory and Implementation Plan and the mapping information contained in it can be used by municipalities to develop the plan for the directly connected paved with catchbasin segment outfalls of municipal roadways. A map(s) is provided on the following page(s) indicating where these outfalls are located, based on the best available information DEC has to date. While the general permit requirements for directly connected paved roads with catchbasins is currently under discussion and not final it is very likely that if these outfalls are eroded they will need to have a scheduled outfall erosion repair. As with other classes of roads covered by this permit the municipality should first check the maps provided. It is suggested (although not currently required) that the following steps be taken to check the maps to determine what outfalls will require municipal attention for erosion repair:

1. Using the provided maps and/or data as a guide confirm that the road draining to this outfall is paved, has at least a single side of curb, has catch basins or drop inlets, and the discharge pipe from those catchbasins is directly discharging to waters of the state. Include any outfall within 500 linear feet of surface waters.
2. Using the maps locate the outfall and note any level of erosion present in the outfall and/or the 500 foot or less long swale between the pipe outlet and waters of the state.
3. Prepare a list of all outfalls with notes pertaining to the erosion based on the Town's ability to repair the erosion (minor, moderate or severe), the extent of erosion (an estimate in linear feet of repair needed including private property if the erosion exists on that property, and a cost estimate if possible).


## Long Island Sound – Connecticut River Watershed Nitrogen Overview



- This map shows an overview of the extent of the Connecticut River watershed including areas of Vermont, New Hampshire, Massachusetts, and Connecticut.

- Above figure taken from USGS – Assessment of Total Nitrogen in the Upper Connecticut River Basin in New Hampshire, Vermont, and Massachusetts, Dec 2002 – Sept 2005. <http://pubs.usgs.gov/sir/2006/5144/pdf/sir2006-5144.pdf>


## New England SPARROW model -- Predicted Sources of Nitrogen Loading in Connecticut River Watershed to LIS



Moore, R.B., Johnston, C.M., Robinson, K.W., and Deacon, J.R., 2004. Estimation of total nitrogen and phosphorus in New England streams using spatially referenced regression models. U.S. Geological Survey Scientific Investigations Report 2004-5012, 42 p. [http://pubs.water.usgs.gov/sir2004\\_5012/](http://pubs.water.usgs.gov/sir2004_5012/)

17

- This figure shows the modeled nitrogen loading contribution per year from the Connecticut River basin to the Long Island Sound.



- This graph shows the breakdown of the modeled nitrogen load from the Connecticut River watershed to the Long Island Sound from various sources.

- Above figures taken from EPA/USGS – Application of NHDPlus for SPARROW nutrient modeling of the Northeastern and Mid-Atlantic Region of the US [http://www.awra.org/orlando2010/presentations/Session22/NHDPlus\\_SPARROW\\_AWRA20100330-good.pdf](http://www.awra.org/orlando2010/presentations/Session22/NHDPlus_SPARROW_AWRA20100330-good.pdf)

# Outfalls draining municipal roads and within 500 feet of a waterbody



# Outfalls draining municipal roads and within 500 feet of a waterbody



Outfalls draining municipal roads and within 500 feet of a waterbody

ROUTE 121 E

SAXTONS RIVER RD

CAMBRIDGEPORT RD

SCHOOLHOUSE RD







31 Rockingham

28 Rockingham

29 Rockingham

30 Rockingham

32 Rockingham

33 Rockingham


35 Rockingham

36 Rockingham

34 Rockingham

37 Rockingham

Subwatersheds



53 Rockingham

Subwatersheds

58 Rockingham

54 Rockingham

3000a Rockingham

59 Rockingham

51 Rockingham

52 Rockingham

47 Rockingham

46 Rockingham



Subwatersheds

# *Subwatershed Data*

*Tables showing calculations and  
Priority drainage area retrofit possibilities*

This is a key showing the abbreviations of the different funding programs listed in the calculation sheets.

<b>Abbreviation Key</b>	
<b>Code</b>	<b>Funding Program</b>
ERP/CWIP	VTDEC Clean Water Initiative Program
LCBP	Lake Champlain Basin Program
SRF	Clean Water State Revolving Loan Fund
VTrans	Vermont Agency of Transportation

This is a key showing the abbreviations of the different stormwater treatment structures or practices listed in the calculation sheets.

<b>Abbreviation Key</b>	
<b>Code</b>	<b>Structure Type</b>
BB	Baffle Box
BFCB	Baffled Catchbasin
BRA	Bioretention Area or Raingarden
BS	Buffer Strip (25' Min.)
CB	Catch Basin
CBI	Catch Basin Insert
CD	Check Dam
CR or ESRD	Impervious Disconnection Credits
DS	Dry Swale
DW	Drywell
EDPMP	Extended Detention Pond with Micropool
GS	Grass Swale
IB	Infiltration Basin
IG	Infiltration Gallery
MOD	Modifications/upgrade to 2002 SW standards
OF	Overland Flow
OGF	Organic Underground Filter
POP	Pocket Pond
PP	Perforated Pipe for infiltration
PS	Pump Station
RDD	Roof Drain Disconnect
RR	Rock Riprap
RS	Riprap Swale
SB	Sediment Basin
SF	Surface Sand Filter
SS-SF	Swirl Separator – Sand Filter
SS OR VS	Swirl Separator
SWPPP	Stormwater Pollution Prevention Plan
TT	Treatment Tank
UD	Underdrain in basin
WL	Wetland (Constructed)
WP	Wet Pond (Retention)
WS	Wet Swale

Rockingham - Subwatershed Prioritization and Recommendations										
Watershed Number	Action List #	Proposed Action	Proposed or Existing Stormwater Treatment Practice	Permit Number	Watershed Area (Acres)	Percent Mapped Impervious Area (MIA)	Sediment Load with Current Reductions (lbs.)	Sediment Load with Priority Action (lbs.)	Nitrogen Load with Current Reductions (lbs.)	Nitrogen Load with Priority Action (lbs.)
1 Rockingham			OF/CB		2.4	37.6	1050	1050	8.75	8.75
2 Rockingham			OF/CB		59.4	11.0	8987	8987	74.89	74.89
3 Rockingham			DW		2.4	20.8	28	28	0.24	0.24
4 Rockingham			CB		1.0	58.6	682	682	5.68	5.68
5 Rockingham			OF/CB		2.2	47.9	1236	1236	10.30	10.30
6 Rockingham			OF/CB		16.8	24.4	4811	4811	40.10	40.10
7 Rockingham			OF/CB		9.0	29.6	2337	2337	19.47	19.47
8 Rockingham			CB		1.2	65.1	929	929	7.74	7.74
9 Rockingham			CB		0.7	49.2	341	341	2.84	2.84
10 Rockingham			CB/OF		2.8	28.0	690	690	5.75	5.75
11 Rockingham	1	Storm drain extension to infiltration basin at WWTP-21 Plant Road	IB/SD/CB/IG/OF		10.7	47.2	4832	483	40.26	4.03
12 Rockingham			OF/CB		6.6	24.1	1358	1358	11.32	11.32
13 Rockingham			OF/CB		7.6	15.6	1066	1066	8.88	8.88
14 Rockingham	1	Bioretention with underdrain or sand filter in park just off circle behind 38 Main St	BRA/OF/CB		5.8	31.0	1589	1113	13.25	11.26
15 Rockingham	2	Bioretention with underdrain across from 49 Main St	BRA/OF/CB		15.9	9.4	1597	1118	13.31	11.31
16 Rockingham	2	Bioretention with underdrain across from 44 Main St	BRA/OF/CB		4.2	27.1	980	686	8.17	6.94
17 Rockingham			OF/CB		2.6	25.7	586	586	4.88	4.88
18 Rockingham			CB		1.0	18.7	228	228	1.90	1.90
19 Rockingham			CB/GS/OF		27.2	6.6	2345	2345	19.54	19.54
20 Rockingham			OF		11.1	16.3	1609	1609	13.41	13.41
21 Rockingham			OF/CB		29.3	7.7	2686	2686	22.38	22.38
22 Rockingham			OF/GS		76.5	3.3	5614	5614	46.78	46.78
23 Rockingham			CB/OF/GS		79.7	4.2	6115	6115	50.96	50.96
24 Rockingham			OF/GS/CB		13.4	17.3	2029	2029	16.91	16.91
25 Rockingham			OF/GS/CB		49.7	12.9	6038	6038	50.32	50.32
26 Rockingham			OF/CB		4.2	34.7	1286	1286	10.72	10.72
27 Rockingham			OF/GS		28.4	13.7	3595	3595	29.96	29.96
28 Rockingham			EDP/CB/GS	4077-9015.1	3.7	45.2	228	228	5.69	5.69
29 Rockingham			OF/CB/GS/SB		4.6	50.2	1811	1811	16.98	16.98
30 Rockingham			OF/CB/GS/SB	3798-9010	2.9	55.1	868	868	9.64	9.64
31 Rockingham			OF/GS/SWPPP	5254-9003	6.4	32.9	1880	1880	15.67	15.67
32 Rockingham			CB/OF/GS/EDP(4)/SWPPP	5734-9015, 5734-9003	23.2	13.7	410	410	10.25	10.25
33 Rockingham			EDP/CR/GS/SB	7291-9015	20.1	14.3	1328	797	14.75	11.80
34 Rockingham			CB/SWPPP	4514-9003	10.6	30.5	3373	3373	28.11	28.11
35 Rockingham			CB/SWPPP/GS	4514-9003	14.8	28.1	3605	3605	30.04	30.04
36 Rockingham			CB		12.5	18.0	1970	1970	16.42	16.42
37 Rockingham			CB/SB(2)/WP(2)/GS	5298-9003	56.5	40.0	7208	7208	105.11	105.11
38 Rockingham			CB/SWPPP	7721-9003	10.5	39.2	4308	4308	35.90	35.90
39 Rockingham			CB/SWPPP/OF	4612-9003	8.1	53.0	3844	3844	32.03	32.03
40 Rockingham			CB		1.4	42.5	677	677	5.64	5.64
41 Rockingham			CB		2.1	73.4	1876	1876	15.64	15.64

Rockingham - Subwatershed Prioritization and Recommendations									
Watershed Number	Water Quality Volume (Acre-Feet)	Channel Protection (Acre-Feet)	Estimated Basin Construction Cost	Estimated Other BMP Construction Cost	Cost of Sediment Removal Per Pound (based on annual sediment load)	Cost of Nitrogen or Phosphorus Removal Per Pound (based on annual nutrient load)	Assistance Program	# LID-Roof Raingardens to Treat Water Quality Volume	Raingarden Cost
1 Rockingham	0.06	0.10					CWIP,SRF	30	\$13,663
2 Rockingham	0.51	0.72					CWIP,SRF	254	\$116,943
3 Rockingham	0.02	0.06					CWIP,SRF	8	\$3,693
4 Rockingham	0.04	0.06					CWIP,SRF	19	\$8,871
5 Rockingham	0.07	0.12					CWIP,SRF	35	\$16,088
6 Rockingham	0.27	0.45					CWIP,SRF	136	\$62,610
7 Rockingham	0.13	0.29					CWIP,SRF	66	\$30,405
8 Rockingham	0.05	0.08					CWIP,SRF	26	\$12,086
9 Rockingham	0.02	FALSE					CWIP,SRF	10	\$4,435
10 Rockingham	0.04	FALSE					CWIP,SRF	20	\$8,975
11 Rockingham	0.27	FALSE	\$250,061		\$58	\$6,901	CWIP,SRF	137	\$62,873
12 Rockingham	0.08	FALSE					CWIP,SRF	38	\$17,672
13 Rockingham	0.06	FALSE					CWIP,SRF	30	\$13,873
14 Rockingham	0.09	FALSE		\$15,000.00	\$31	\$7,550	CWIP,SRF	45	\$20,684
15 Rockingham	0.09	FALSE		\$15,000.00	\$31	\$7,512	CWIP,SRF	45	\$20,787
16 Rockingham	0.06	FALSE		\$15,000.00	\$51	\$12,244	CWIP,SRF	28	\$12,754
17 Rockingham	0.03	FALSE					CWIP,SRF	17	\$7,626
18 Rockingham	0.01	FALSE					CWIP,SRF	6	\$2,964
19 Rockingham	0.13	FALSE					CWIP,SRF	66	\$30,516
20 Rockingham	0.09	0.20					CWIP,SRF	46	\$20,943
21 Rockingham	0.15	FALSE					CWIP,SRF	76	\$34,949
22 Rockingham	0.32	0.28					CWIP,SRF	159	\$73,053
23 Rockingham	0.35	0.37					CWIP,SRF	173	\$79,569
24 Rockingham	0.11	0.25					CWIP,SRF	57	\$26,408
25 Rockingham	0.34	FALSE					CWIP,SRF	171	\$78,578
26 Rockingham	0.07	FALSE					CWIP,SRF	36	\$16,741
27 Rockingham	0.20	FALSE					CWIP,SRF	102	\$46,780
28 Rockingham	0.06	FALSE					CWIP,SRF	32	\$14,810
29 Rockingham	0.13	FALSE					CWIP,SRF	64	\$29,457
30 Rockingham	0.08	FALSE					CWIP,SRF	41	\$18,819
31 Rockingham	0.11	FALSE					CWIP,SRF	53	\$24,466
32 Rockingham	0.12	0.35					CWIP,SRF	58	\$26,689
33 Rockingham	0.13	FALSE					CWIP,SRF	63	\$28,795
34 Rockingham	0.21	FALSE					CWIP,SRF	106	\$48,769
35 Rockingham	0.20	FALSE					CWIP,SRF	102	\$46,913
36 Rockingham	0.11	0.25					CWIP,SRF	56	\$25,633
37 Rockingham	1.02	FALSE					CWIP,SRF	510	\$234,486
38 Rockingham	0.27	FALSE					CWIP,SRF	135	\$62,292
39 Rockingham	0.24	FALSE					CWIP,SRF	121	\$55,578
40 Rockingham	0.04	FALSE					CWIP,SRF	19	\$8,812
41 Rockingham	0.11	FALSE					CWIP,SRF	53	\$24,415

Rockingham - Subwatershed Prioritization and Recommendations										
Watershed Number	Action List #	Proposed Action	Proposed or Existing Stormwater Treatment Practice	Permit Number	Watershed Area (Acres)	Percent Mapped Impervious Area (MIA)	Sediment Load with Current Reductions (lbs.)	Sediment Load with Priority Action (lbs.)	Nitrogen Load with Current Reductions (lbs.)	Nitrogen Load with Priority Action (lbs.)
42 Rockingham			CB/SWPPP	4800-9003, 7721-9003	3.0	79.9	2677	2677	22.31	22.31
43 Rockingham			OF/GS		1.5	52.6	927	927	7.73	7.73
44 Rockingham	1	Bioretention or rain garden along RR tracks at 17 Depot St	BRA/OF/GS		4.6	80.0	4193	2516	34.94	20.97
45 Rockingham			CB/SWPPP	7721-9003	5.9	56.6	3549	3549	29.58	29.58
46 Rockingham			CB		12.1	62.4	9832	9832	81.93	81.93
47 Rockingham			CB		4.9	57.2	2845	2845	23.71	23.71
48 Rockingham			CB/GS/OF		5.8	53.6	3085	3085	25.71	25.71
49 Rockingham			CB		3.5	71.3	3210	3210	26.75	26.75
50 Rockingham			OF/WP		3.8	15.0	71	71	1.76	1.76
51 Rockingham			CB		5.5	53.1	3478	3478	28.99	28.99
52 Rockingham			CB		1.5	55.9	1098	1098	9.15	9.15
53 Rockingham	3	Swirl separator or sand filter at outfall	VS-SF/CB/GS		80.8	20.0	19357	11614	161.31	120.98
54 Rockingham	1	Extended Detention Micropool behind 28 Pearce Circle	EDPMP/CB/GS/OF		117.5	11.2	13064	7838	108.87	87.09
55 Rockingham	2	Swirl separator, linear infiltration basin or sand filter at both outfalls, north and south of WWTP. Possible diversion of north outfall to pond in 50 Rockingham.	VS-SF/CB/DW		238.4	34.1	94242	18848	785.35	471.21
56 Rockingham			CB/GS/OF		14.7	16.5	2152	2152	17.94	17.94
57 Rockingham			CB/SWPPP	4700-9003	17.4	41.0	7503	7503	62.53	62.53
58 Rockingham			CB/GS/OF		51.4	12.0	8248	8248	68.73	68.73
59 Rockingham	1	Modify sediment basin to raingarden behind 31b Cherry Hill St	MOD/CB/DW/SB		79.0	36.7	33683	31999	280.69	266.66
60 Rockingham	2	Infiltration basin between 984 & 986 Saxtons River Rd	IB/CB		5.5	26.2	1685	168	14.04	1.40
3000a Rockingham			CB		0.06	73.8	52	52	0.43	0.43
3000b Rockingham	1	Connect CB to storm on Blake Street	OF/GS/CB		5.4	8.2	508	508	4.23	4.23
3000e Rockingham			CB		0.5	72.9	0	0	0.00	0.00
3000c Rockingham			CB		0.1	89.3	0	0	0.00	0.00
3000d Rockingham	1	Redirect drain to River	CB		0.04	100.0	48	48	0.40	0.40




Rockingham - Subwatershed Prioritization and Recommendations									
Watershed Number	Water Quality Volume (Acre-Feet)	Channel Protection (Acre-Feet)	Estimated Basin Construction Cost	Estimated Other BMP Construction Cost	Cost of Sediment Removal Per Pound (based on annual sediment load)	Cost of Nitrogen or Phosphorus Removal Per Pound (based on annual nutrient load)	Assistance Program	# LID-Roof Raingardens to Treat Water Quality Volume	Raingarden Cost
42 Rockingham	0.17	FALSE					CWIP,SRF	84	\$38,713
43 Rockingham	0.05	FALSE					CWIP,SRF	26	\$12,069
44 Rockingham	0.24	FALSE		\$25,000.00	\$15	\$1,789	CWIP,SRF	119	\$54,565
45 Rockingham	0.22	FALSE					CWIP,SRF	112	\$51,320
46 Rockingham	0.56	FALSE					CWIP,SRF	278	\$127,936
47 Rockingham	0.16	FALSE					CWIP,SRF	80	\$37,017
48 Rockingham	0.17	FALSE					CWIP,SRF	87	\$40,141
49 Rockingham	0.18	FALSE					CWIP,SRF	91	\$41,767
50 Rockingham	0.02	FALSE					CWIP,SRF	10	\$4,589
51 Rockingham	0.20	FALSE					CWIP,SRF	98	\$45,265
52 Rockingham	0.06	FALSE					CWIP,SRF	31	\$14,289
53 Rockingham	1.10	FALSE	\$251,888		\$33	\$6,246	CWIP,SRF	548	\$251,888
54 Rockingham	0.74	1.45		\$50,000.00	\$10	\$2,296	CWIP,SRF	370	\$169,999
55 Rockingham	5.33	FALSE	\$1,226,364		\$16	\$3,904	CWIP,SRF	2666	\$1,226,364
56 Rockingham	0.12	FALSE					CWIP,SRF	61	\$28,008
57 Rockingham	0.47	FALSE					CWIP,SRF	236	\$108,488
58 Rockingham	0.47	FALSE					CWIP,SRF	233	\$107,328
59 Rockingham	1.91	FALSE		\$5,000.00	\$3	\$356	CWIP,SRF	953	\$438,309
60 Rockingham	0.10	0.16	\$87,200		\$58	\$6,901	CWIP,SRF,Vtrans	48	\$21,925
3000a Rockingham	0.00	FALSE					CWIP,SRF	1	\$677
3000b Rockingham	0.03	FALSE		\$5,000.00			CWIP,SRF	14	\$6,612
3000e Rockingham	0.02	FALSE					CWIP,SRF	11	\$5,277
3000c Rockingham	0.01	FALSE					CWIP,SRF	4	\$1,921
3000d Rockingham	0.00	FALSE		\$5,000.00			CWIP,SRF	1	\$621

# *Target Maps*

*Showing Priority Action List  
Drainage Areas*

*And Potential Retrofit Locations*

**Subwatershed: 11**  
**Action List: 1**




Potential for a storm drain extension to an infiltration basin at the WWTP to treat the runoff from subwatershed 11 before it enters the receiving water.

## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.


The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available

**Subwatershed: 14**  
**Action List: 1**




Potential for a bioretention area in Subwatershed 14 to treat runoff before it enters the receiving water.

## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



### Stormwater points

- Pipe Cross (not connected)
- Catchbasin
- Dry Well
- Drop Inlet
- Grate/Curb Inlet
- Yard drain
- CB tied to sanitary sewer
- Junction Box
- Stormwater Manhole
- Outfall
- Culvert inlet
- Culvert outlet
- Pond outlet structure
- Treatment feature (see notes)
- Retrofit
- Unknown Point
- Information Point

### Stormwater line

- Storm line
- Storm line (old Sanitary line)
- Tunnel (storm)
- Combined sewer
- Sanitary line
- Swale
- Footing drain
- Under drain
- Roof drain
- Infiltration pipe
- French drain
- Trench drain
- Emergency spillway
- Stream
- Overland flow

### NRCS - Soils

- A
- B
- C
- D

### SubwatershedID

- Priority Subwatershed
- Stormwater Treatment Area
- Potential Stormwater Treatment Area


Creator: Jim Pease, David Ainley  
DEC - WSMD - Ecosystem Restoration Program

Plotted Date: 5/8/2017

Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey


Imagery Source: VCGI Best Available

**Subwatershed: 15 & 16**  
**Action List: 2**



Potential for a bioretention area in Subwatershed 16 to treat runoff before it enters the receiving water.

Potential for a bioretention area in Subwatershed 15 to treat runoff before it enters the receiving water.




## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.




<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available



**Subwatershed: 44 & 3000d**  
**Action List: 1**




## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



- Stormwater points**
- Pipe Cross (not connected)
  - Catchbasin
  - Dry Well
  - Drop Inlet
  - Grate/Curb Inlet
  - Yard drain
  - CB tied to sanitary sewer
  - Junction Box
  - Stormwater Manhole
  - Outfall
  - Culvert inlet
  - Culvert outlet
  - Pond outlet structure
  - Treatment feature (see notes)
  - Retrofit
  - Unknown Point
  - Information Point

- Stormwater line**
- Storm line
  - Storm line (old Sanitary line)
  - Tunnel (storm)
  - Combined sewer
  - Sanitary line
  - Swale
  - Footing drain
  - Under drain
  - Roof drain
  - Infiltration pipe
  - French drain
  - Trench drain
  - Emergency spillway
  - Stream
  - Overland flow



- NRCS - Soils**
- A
  - B
  - C
  - D

- SubwatershedID**
- Priority Subwatershed
  - Stormwater Treatment Area
  - Potential Stormwater Treatment Area

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available

**Subwatershed: 53**  
**Action List: 3**

Potential for a swirl separator and sand filter in subwatershed 53 to treat runoff before it enters the receiving water.




### Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.




<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available



**Subwatershed: 54**  
**Action List: 1**

Potential for an extended detention micropool in subwatershed 54 to treat runoff before it enters the receiving water.




## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available



Subwatershed: 55

Action List: 2

Subwatershed: 3000b

Action List: 1

Connect the catchbasin to the storm from the sewer on Blake street.

3000b

55

Potential for a swirl separator, linear infiltration basin or sand filter at both outlets and modification of the pond north of the WWTP to treat the runoff from subwatershed 55 before it enters the receiving water.




0 0.05 0.1 0.2 Miles

# Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



### Stormwater points

- Pipe Cross (not connected)
- Catchbasin
- Dry Well
- Drop Inlet
- Grate/Curb Inlet
- Yard drain
- CB tied to sanitary sewer
- Junction Box
- Stormwater Manhole
- Outfall
- Culvert inlet
- Culvert outlet
- Pond outlet structure
- Treatment feature (see notes)
- Retrofit
- Unknown Point
- Information Point

### Stormwater line

- Storm line
- Storm line (old Sanitary line)
- Tunnel (storm)
- Combined sewer
- Sanitary line
- Swale
- Footing drain
- Under drain
- Roof drain
- Infiltration pipe
- French drain
- Trench drain
- Emergency spillway
- Stream
- Overland flow

### NRCS - Soils

- A
- B
- C
- D

### SubwatershedID

- Priority Subwatershed
- Stormwater Treatment Area
- Potential Stormwater Treatment Area

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/8/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available



**Subwatershed: 59**  
**Action List: 1**




Potential to modify the sedimentation basin to a raingarden at 31b Cherry Hill Street to treat the runoff from subwatershed 59 before it enters the receiving water.

## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.


The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
DEC - WSMD - Ecosystem Restoration Program  
Plotted Date: 5/8/2017  
Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
Imagery Source: VCGI Best Available

**Subwatershed: 60**  
**Action List: 2**




## Rockingham, VT

DEC Stormwater Infrastructure Mapping Project

This map shows high priority subwatersheds which are ranked by connectedness, percent of impervious cover, field observations, and potential retrofit measures and locations.

The data shown on this map is only as accurate as the available sources and field observations allowed and should be used as a basic planning level tool only.



<p><b>Stormwater points</b></p> <ul style="list-style-type: none"> <li> Pipe Cross (not connected)</li> <li> Catchbasin</li> <li> Dry Well</li> <li> Drop Inlet</li> <li> Grate/Curb Inlet</li> <li> Yard drain</li> <li> CB tied to sanitary sewer</li> <li> Junction Box</li> <li> Stormwater Manhole</li> <li> Outfall</li> <li> Culvert inlet</li> <li> Culvert outlet</li> <li> Pond outlet structure</li> <li> Treatment feature (see notes)</li> <li> Retrofit</li> <li> Unknown Point</li> <li> Information Point</li> </ul>	<p><b>Stormwater line</b></p> <ul style="list-style-type: none"> <li> Storm line</li> <li> Storm line (old Sanitary line)</li> <li> Tunnel (storm)</li> <li> Combined sewer</li> <li> Sanitary line</li> <li> Swale</li> <li> Footing drain</li> <li> Under drain</li> <li> Roof drain</li> <li> Infiltration pipe</li> <li> French drain</li> <li> Trench drain</li> <li> Emergency spillway</li> <li> Stream</li> <li> Overland flow</li> </ul>	<p><b>NRCS - Soils</b></p> <ul style="list-style-type: none"> <li> A</li> <li> B</li> <li> C</li> <li> D</li> </ul>	<p><b>SubwatershedID</b></p> <ul style="list-style-type: none"> <li> Priority Subwatershed</li> <li> Stormwater Treatment Area</li> <li> Potential Stormwater Treatment Area</li> </ul>
--	---	---	---

Creator: Jim Pease, David Ainley  
 DEC - WSMD - Ecosystem Restoration Program  
 Plotted Date: 5/30/2017  
 Data Sources: VTRANS Roads data, VT Hydrography data set, DEC Stormwater database, NRCS soils survey  
 Imagery Source: VCGI Best Available

# *Spill Control*

*and*

*Vermont Hazardous Waste Management Regulations*

## **Have a spill control plan for accidental spills at municipal facilities and on municipal streets**

These stormwater infrastructure maps show the connectivity of the stormwater system for the municipality as accurately as it could be determined with the collected and existing data. In the event of a spill this can be a valuable tool for controlling spills and in spill response.

Towns should be equipped with suitable equipment to contain and clean up spills of hazardous materials. Accidental spills of materials can be sources of runoff pollution if not addressed appropriately. If possible Towns should be prepared to address spills on municipal streets while at the same time contacting the state Waste Management Division. DPW managers should be aware of all applicable requirements and should contact regulatory authorities if requirements are not known.

All spills should be cleaned up immediately after they occur. For municipal facilities the creation of a site specific spill control and response plan in combination with spill response training for designated on-site personnel can be effective in dealing with accidental spills and preventing the contamination of soil, water, and runoff. Preparation of a spill containment, control, and countermeasures (SPCC) plan might be required to meet regulatory requirements (e.g., requirements regarding storage of specified chemicals above certain volume thresholds).

Even if a formal plan is not required, preparing one is a good idea. In general, an SPCC plan should include guidance to site personnel on the following:

- Proper notification when a spill occurs;
- Site responsibility with respect to addressing the cleanup of a spill;
- Stopping the source of a spill;
- Cleaning up a spill;
- Proper disposal of materials contaminated by the spill;
- Location of spill response equipment programs; and
- Training for designated on-site personnel.


A periodic spill “fire drill” should be conducted to help prepare Town personnel in the event of a spill.

## ***Spill Prevention and Response Measures***

### **Catch Basin Inserts**

Catch Basin Inserts (Drain Guards / Sediment Traps) protect our rivers and streams by capturing sediment, debris, oil and grease at storm water catch basins. Catch Basin Inserts are an economical and effective method to protect you from costly clean-up work.

The standard filter material is a non-woven geotextile with built-in overflow ports for cases of abnormally high water flow or over-filled filter bags. Catch Basin Inserts are available with a replaceable 5” x 15” oil absorbent boom that floats to absorb any oil, gas or diesel entering a storm water catch basin.



### Urethane Drain Protector

Urethane Drain Protectors are positive sealing drain covers that ensure spills do not enter drains. Drain Protectors are environmentally safe and resistant to chemicals, solvents and hydrocarbons. After use, the Drain Protector can be washed and stored in its tube storage container.



### Absorbent Socks

Absorbent socks are flexible tubes used to contain and clean-up spilled fluids. Socks are widely used in industrial applications and are ideal for Spill Kits. Fast spreading spills are quickly stopped with a sock.



### Drums & Intermediate Bulk Containers (IBC's)



New and reconditioned steel drums are ideal for storing solid and liquid waste. Poly drums available for durable outdoor storage or for building your own spill kits. Steel and poly drums are available in both tight-head (TH) and full open-head styles (FOH).



### Pads & Rolls

Absorbent pads and rolls made from polypropylene fibers are the most popular form of absorbents on the market. Various types of absorbent pads and rolls can be used for different liquids and site applications.

The most widely used absorbent pads and rolls are oil-only (white) and universal (grey). Pads and rolls are great for spills on land, easily absorbing 20 to 25 times their own weight in recovered liquid. Rolls can easily be cut to the exact size required.



water or

### Booms

#### Linkable Absorbent Booms

Absorbent booms are ideal for containing and cleaning up spills on water. Booms repel water and float even when completely saturated. Absorbent booms are constructed with a strong mesh outer skin encasing non-linting and highly absorbent polypropylene filler. Linkable booms come complete with end rings and clips attached to nylon rope running the length of the boom.



**Collection basins**

Collection basins are permanent structures in which large spills or contaminated storm water is contained and stored before cleanup or treatment. Collection basins are designed to receive spills, leaks, etc., and to prevent pollutants from being released into the environment. Unlike containment dikes, collection basins can receive and contain materials from many locations across a facility.

**Containment diking**

Containment dikes are temporary or permanent earth or concrete berms or retaining walls that are designed to hold spills. Diking can be used at any industrial facility, but is most common for controlling large spills or releases from liquid storage and transfer areas. Diking can provide one of the best protective measures against the contamination of storm water because it surrounds the area of concern and keeps spilled materials separated from the storm water outside of the diked area.

**Curbing**

Similar to containment diking, a curb is a barrier that surrounds an area of concern. Unlike diking, curbing is unable to contain large spills and is usually implemented on a small-scale basis. However, curbing is common at many facilities and in small areas where liquids are handled and transferred.

**Granular Absorbents**

A variety of granular and powdered absorbents are available for the effective clean-up of spills on streets, construction sites and in repair shops. These products absorb spilled liquids of various kinds to greatly lower the viscosity, aiding in the clean-up of the spill.

**Sorbents, Gels, and Foams**

Sorbents are compounds that immobilize materials by surface absorption or adsorption in the sorbent bulk. Gelling agents interact with the spilled chemical(s) by concentrating and congealing to form a rigid or viscous material more conducive to a mechanical cleanup. Foams are mixtures of air and aqueous solutions of proteins and surfactant-based foaming agents. The primary purpose of foams is to reduce the vapor concentration above the spill surface, thereby controlling the rate of evaporation.

#### § 7-104 NOTIFICATION REQUIREMENTS

- (a) Except for persons who have been issued a temporary identification number pursuant to **subsection (d) of this section**, any person who generates or transports hazardous waste or who owns or operates a transfer facility or a facility for the treatment, storage, use, disposal, or recycling of hazardous waste shall notify the Secretary of such activity. In addition, persons managing waste under the provisions of either the used oil management standards of subchapter 8, or the universal waste management standards of subchapter 9, shall notify the Secretary of such activity as required under those subchapters. Notification shall be made by accurately and completely filling out the **Vermont Hazardous Waste Handler Site ID Form** (provided by the Secretary) in accordance with the form's instructions.
- (b) Notification is required upon transferal of ownership of an entity that was required to notify the Secretary under **subsection (a) of this section**.
- (c) Persons subject to the requirements of this section shall maintain an up-to-date **Vermont Hazardous Waste Handler Site ID Form** filed with the Secretary that accurately describes current waste activity and waste generation. A generator may notify the Secretary of a change in generator status by marking the appropriate status level on the **Hazardous Waste Generator Registration Fee Assessment** form that is sent to generators each year pursuant to § 7-708(e).
- (d) The Secretary may issue a temporary identification number to persons who have generated hazardous waste only from an episodic event.

#### § 7-105 EMERGENCY AND CORRECTIVE ACTIONS

- (a) Emergency actions
  - (1) In the event of a discharge of hazardous waste or a release of a hazardous material, the person in control of such waste or material shall:
    - (A) Take all appropriate immediate actions to protect human health and the environment including, but not limited to, emergency containment measures and notification as described below; and
    - (B) Take any further clean-up actions as may be required and approved by federal, state, or local officials, or corrective actions as specified under **subsection (b) of this section** so that the discharged waste or released material and related contaminated materials no longer present a hazard to human health or the environment.



(2) Reporting

- (A) All discharges and/or releases that meet any of the following criteria shall be immediately reported to the Secretary by the person or persons exercising control over such waste by calling the Waste Management & Prevention Division at (802) 828-1138, Monday through Friday, 7:45 a.m. to 4:30 p.m. or the Department of Public Safety, Emergency Management Division at (800) 641-5005, 24 hours/day:
- (i) A discharge of hazardous waste, or release of hazardous material that exceeds 2 gallons;
  - (ii) A discharge of hazardous waste, or release of hazardous material that is less than or equal to 2 gallons and poses a potential or actual threat to human health or the environment; or
  - (iii) A discharge of hazardous waste, or release of hazardous material that equals or exceeds its corresponding reportable quantity under CERCLA as specified under **40 CFR § 302.4**.

**Note:** Under the Federal Water Pollution Control Act, certain spills of “oil” and/or “hazardous substances” are prohibited and must be reported pursuant to the requirements of **40 CFR Part 110** / Discharge of Oil. Certain spills of hazardous substances must also be reported pursuant to CERCLA. In both cases, the National Response Center must be notified at (800) 424-8802. Finally, in addition to federal and state spill reporting, EPCRA requires that spills are also reported to local authorities.

- (B) A written report shall be submitted to the Secretary within ten (10) days following any discharge or release subject to **subsection (a)(1) of this section**. The report should be sent to: The Vermont Department of Environmental Conservation, Waste Management & Prevention Division, 1 National Life Drive – Davis 1, Montpelier, VT 05620-3704. The person responsible for submitting the written report may request that it not be submitted for small discharges and/or releases that were reported pursuant to **subsection (a)(2)(A) of this section**, and that have been entirely remediated within the ten (10) day period immediately following the discharge and/or release.
- (3) If the discharge or release occurred during transportation, the transporter shall, in addition to notifying the Secretary:
- (A) Notify the National Response Center at (800) 424-8802 or (202) 426-2675, if required by **49 CFR § 171.15**; and

- (B) Report in writing to the Director, Office of Hazardous Materials Regulations, Materials Transportation Bureau, Department of Transportation, Washington, D.C. 20590, if required by **49 CFR § 171.16**; and
  - (C) A water (bulk shipment) transporter who has discharged hazardous wastes must give the same notice as required by **33 CFR § 153.203** for oil and hazardous substances.
- (4) If a discharge or release occurs and the Secretary determines that immediate removal of the waste is necessary to protect human health or the environment, the Secretary may authorize its removal by unpermitted transporters without the preparation of a manifest. Such hazardous waste may be transported to a site authorized by the Secretary under the emergency certification provisions of **§ 7-503** to temporarily accept hazardous waste generated during an emergency clean-up of a discharge or release.
- (5) In the case of an explosives or munitions emergency response, if a Federal, State, Tribal or local official acting within the scope of his or her official responsibilities, or an explosives or munitions emergency response specialist, determines that immediate removal of the material or waste is necessary to protect human health or the environment, that official or specialist may authorize the removal of the material or waste by transporters who do not have EPA identification numbers or hold Vermont hazardous waste transportation permits and without the preparation of a manifest. In the case of emergencies involving military munitions, the responding military emergency response specialist's organizational unit must retain records for three years identifying the dates of the response, the responsible persons responding, the type and description of material addressed, and its disposition.
- (6) All clean-up debris and residues that are hazardous waste must be stored in leak-proof containers that are covered so as to prevent contact of the waste with precipitation or run-on from precipitation.
- (7) All clean-up debris and residues that are hazardous waste must be transported ultimately to:
- (A) A designated facility;
  - (B) A person authorized by the Secretary to use such waste if the waste has been delisted pursuant to **§ 7-218**;
  - (C) Some other location specified and authorized by the Secretary to receive clean up debris and residues if the waste has been delisted pursuant to **§ 7-218**; or
  - (D) For hazardous waste not defined as hazardous in 40 CFR Part 261 (i.e., waste regulated as hazardous by Vermont), to a facility, that is not a designated

facility, located in a state other than Vermont provided the facility can receive such waste under applicable state and local laws, regulations and ordinances.

(b) Corrective actions

- (1) If a discharge of hazardous waste, or a release of hazardous material has not been adequately addressed under **subsection (a)(1)(A) of this section** the Secretary shall require that the person or persons responsible pursuant to **10 V.S.A. § 6615** complete the following:
  - (A) Engage the services of an environmental consultant experienced in the investigation and remediation of hazardous waste-contaminated sites; and
  - (B) Within thirty (30) days from either the date of the discharge/release or the date that the release was discovered if the date of discharge/release is not known, or within a period of time established by an alternative schedule approved by the Secretary, submit for approval by the Secretary a work plan for an investigation of the contaminated site (i.e., site investigation) prepared by the environmental consultant. The site investigation shall define the nature, degree and extent of the contamination; and shall assess potential impacts to human health and the environment (refer to **Chapter 2** of the Agency's "**Investigation and Remediation of Contaminated Properties Procedure**" which is available from the Secretary upon request); and
  - (C) Perform the site investigation within either ninety (90) days of receiving written approval of the work plan by the Secretary, or a period of time established by an alternative schedule approved by the Secretary. A report detailing the findings of the site investigation shall be sent to the Secretary for review; and
  - (D) Within either thirty (30) days from the date of final acceptance of the site investigation report by the Secretary, or a period of time established by an alternative schedule approved by the Secretary, submit a corrective action plan prepared by the environmental consultant (refer to **Chapter 4** of the Agency's "**Investigation and Remediation of Contaminated Properties Procedure**" which is available from the Secretary upon request); and
  - (E) Implement the corrective action plan within either ninety (90) days of receiving written approval of the plan by the Secretary, or a period of time established by an alternative schedule approved by the Secretary. The corrective action activity shall continue until the contamination is remediated to levels approved by the Secretary; and
  - (F) Submit to the Secretary all investigative, corrective action and monitoring reports, and all analytical results related to **subsections (b)(1)(C) through (E) of this section**, as they become available.

- (2) A used or fired military munition is a waste and is potentially subject to corrective action authorities pursuant to **10 V.S.A. § 6615**, and the process described by **subsection (b)(1) of this section** if the munition lands off-range and is not promptly rendered safe or retrieved. Any imminent and substantial threats associated with any remaining material must be addressed. If remedial action is infeasible, the operator of the range must maintain a record of the event for as long as any threat remains. The record must include the type of munition and its location (to the extent the location is known).

#### § 7-106 LAND DISPOSAL RESTRICTIONS

- (a) Certain hazardous wastes shall not be disposed of in or on the land. **40 CFR Part 268**, which is hereby incorporated by reference, except for **40 CFR §§ 268.5, 268.6, and 268.42(b)**, identifies those wastes which shall not be land disposed and describes the limited circumstances under which an otherwise prohibited waste may continue to be land disposed. The authority for implementing the CFR sections not incorporated by reference remains with the EPA.

**Note:** A copy of 40 CFR Part 268 (the Land Disposal Restrictions rule), as incorporated by these regulations, is available from the Secretary upon request.

- (b) In addition to the prohibitions of **40 CFR Part 268**, the Secretary may restrict the land disposal of any hazardous waste in the State of Vermont:
  - (1) Which may present an undue risk to human health or the environment, immediately or over a period of time; or
  - (2) Which would be incompatible with the **groundwater protection rule and strategy** of chapter 12 of the environmental protection rules.
- (c) Dilution of hazardous waste subject to the land disposal restrictions of 40 CFR Part 268 is prohibited pursuant to **40 CFR § 268.3**.

#### § 7-107 ENFORCEMENT

- (a) Information that the generation, transportation, treatment, storage or disposal of hazardous waste may present an actual or potential threat to human health or the environment, or is a violation of the **10 V.S.A. chapter 159**, or these regulations, or any term or condition of certification, order, or assurance, may serve as grounds for an enforcement action by the Secretary, including, but not limited to:
  - (1) After notice and opportunity for hearing, issuing an order directing any person to take such steps as are necessary to: